TCCTV HOW TO
Repair/Reset Your Firestick Remote

1. Press and hold the Left button, Menu button, and Back button at the same time. Hold them for 10 seconds.

2. Release the buttons and wait 60 seconds.

3. Remove the batteries from your remote.

4. Unplug your Fire TV Stick and wait 60 seconds.

5. Put the batteries back in your remote, and then plug in your Fire TV Stick.

6. Once the Home screen appears, press and hold the Home button for 40 seconds.

7. Wait 60 seconds for setup to complete.

LEFT BUTTON

BACK BUTTON

MENU BUTTON

TCC
519-263-2211
www.tcc.on.ca